


# P73 Piezo Objective Scanner


## User Manual

Version: V1.0



This document describes the following products:

- P73.Z200S    P73.Z200K
- P73.Z500S    P73.Z500K
- P73.Z1000S    P73.Z1000K



# DECLARATION

This user manual is applicable to P73 Piezo Objective Scanner, for your smooth and correct use of this product, please read this manual carefully before using it. Please follow the instructions in the installation and use process. Improper operation may cause injury to the operator and/or damage to the product, so it is required that the entire installation and operation process should be completed by professionals with a certain foundation and a certain understanding of product principles, or under the guidance of a professional.

If you disassemble or transform the product without permission, our company will not be responsible for any consequences arising therefrom.

To change the product model and other false sales of our company's products are illegal, users should be vigilant. Once found, you should actively report or contact our company, jointly crack down on illegal acts, and prevent fraud and economic losses. CoreMorrow will investigate for the legal responsibility of the illegal subject and related party.

With the continuous development and innovation of technology, CoreMorrow will timely add the latest information to the manual as required. If you need, please contact us, or to our website [www.coremorrow.com](http://www.coremorrow.com) for download, we apologize for any inconvenience caused to you.

# Contents

1. Introduction .....	2
1.1 Purpose and content .....	2
1.2 Symbol and meaning.....	2
1.3 Users of This Manual .....	2
1.4 Manual Lost and Reissued.....	2
2. Safety Guide.....	3
3. Product Overview .....	4
3.1 Product Introduction .....	4
3.2 Product Features .....	5
3.3 Motion Direction .....	5
4. Operating environment .....	5
5. Installation and operation.....	6
5.1 Installation and Precautions .....	6
5.2 Load .....	7
5.3 Operating.....	8
6. Transportation and inspection .....	9
6.1 Transportation.....	9
6.2 Open-Box Inspection.....	9
7. Maintenance and Treatment.....	10
7.1 Problem Handling.....	10
7.2 Daily maintenance .....	11
7.3 Disposal.....	11
8. Customer Service .....	12
9. Contact us.....	12

## 1. Introduction >>

### 1.1 Purpose and content

- ▶ This manual is mainly for your smooth and correct use of P73 Piezo Objective Scanner.
- ▶ The manual contains all the necessary information for P73 Piezo Objective Scanner.
- ▶ Introduction of the precautions during installation and use.

### 1.2 Symbol and meaning



**DANGER:** Improper handling may could cause injury to the operator.



**Attention:** Improper handling can cause damage to the equipment.

- ▶ No order between items.

1. Please operating in order.
- 2.

### 1.3 Users of This Manual

The default user of this manual has knowledge of piezoelectric products and controllers, and has a certain basis for their installation and use.

### 1.4 Manual Lost and Reissued

If this manual is lost, please contact CoreMorrow. We will send you the latest version of the user manual.

## 2. Safety Guide

P73 Piezo Objective Scanner is designed with the most advanced technology and safety standards for your own safety and the correct use of the product, please observe the following points when in use.



A change in temperature and pressure will charge the piezoelectric actuator, and the actuator will remain energized for a period of time when it is disconnected from the controller. So the operator should pay attention to when in use.

- ▶ Do not disassemble P73 Piezo Objective Scanner;
- ▶ Discharge P73 before installation, which can be done by connecting to the controller;
- ▶ Do not unplug the wire connecting with controller during operation;
- ▶ Before use, check whether the connection wire of the product is in good condition and whether the product and the controller are effectively grounded. During operation, strictly standardize the operation. Do not touch the product (up to 150V voltage) with your hand when power on, in case of danger.



In order to prevent damage to the product caused by improper operation, the following points should be paid attention to when in use.

- ▶ P73 Piezo Objective Scanner is used in a dust-free, oil-free and lubricant-free environment;
- ▶ As the product is designed with flexible structure, it is recommended that the load should not exceed load capacity of product. When loading, DO NOT apply torque force and DO NOT pry or twist the load surface, so as not to damage the structure;
- ▶ Recommended voltage range is 0~120V for long-term use and lifetime;
- ▶ Do not disassemble the product to avoid damage;
- ▶ Avoid stretching and bending the cable interface to prevent damage to the cable;
- ▶ Use the dedicated cable provided by CoreMorrow to connect P73 Piezo Objective Scanner to controller;
- ▶ Do not connect via an extension cable casually, if you need a longer cable, please contact CoreMorrow.

## 3. Product Overview

### 3.1 Product Introduction

P73 Piezo Objective Scanner has the following advantages:

▶ High performance piezo stack:

P73 Piezo Objective Scanner is driven by a highly reliable ceramic actuator with a fully insulated structure, so its performance and service life are far better than the traditional actuator. The insulating layer can effectively prevent the piezoelectric ceramic from being damaged when exposed to moisture. Therefore, the stability of piezoelectric ceramics can be guaranteed under extreme circumstances. Compared with traditional driving mechanism, there are no transmission parts and friction. Therefore, ceramic actuator has the characteristics of no rebound, no maintenance, and no wear, etc.

▶ Flexible hinge structure:

P73 Piezo Objective Scanner adopts flexible hinge mechanism has advantages of no friction, high positioning accuracy. Flexible hinge is an element not affected by static and dynamic friction, based on the elastic deformation of metal material (e.g., steel) , there is no rolling and sliding parts. Flexible unit has very high load capacity and stiffness. Hinge guide needs no maintenance and no wear and tear. Suitable for a wide range of temperatures, no lubricating oil is required.

▶ Strain sensor

Strain sensor detects the position information by its own expansion. They are fixed in the proper position of the transmission part and measure the displacement of the moving part. This type of position measurement is made by contact and indirect measurement. So the displacement of the moving platform is measured by measuring lever, guide hinge, or piezoelectric ceramic stack.

P73 Piezo Objective Scanner is a large-loading scanner with Z travel range up to 1000μm. It adopts flexible hinge design with no friction, no yaw and high closed-loop control positioning accuracy. Separate thread adapter design, can be adapted to a variety of types of

microscopes, widely used in a wide range of microscopic imaging, two-photon microscope and other fields.

### 3.2 Product Features

- ▶ Strain gauge sensor, high positioning accuracy.
- ▶ High focusing stability.
- ▶ Multiple adapter models are available.

### 3.3 Motion Direction




FIG. 1 Motion Direction of P73 Piezo Objective Scanner

## 4. Operating environment

- ▶ Operating temperature: -20~80℃
- ▶ Environment free of dust, clean, and non-corrosive substances
- ▶ Relative humidity: <60%
- ▶ Recommended voltage between 0 and 120V for long-term and high-reliability operation.

### 5. Installation and operation

Safety check should be carried out before installation, such as whether the connection wire is damaged or broken, whether the drive power supply is grounded, etc.

#### 5.1 Installation and Precautions

Safety check should be carried out before installation, such as whether the connection wire is damaged or broken, whether the drive power supply is grounded, etc.

Installation of P73 Piezo Objective Scanner is shown as following

- 1.Screw the objective adapter into P73 Piezo Objective Scanner and tighten it;
- 2.Screw the objective lens into the objective adapter and tighten it;
- 3.Connecting the installed objective scanner and the microscope and tighten it;

P73 Piezo Objective Scanner




FIG.2 Installation diagram

#### Mounting notes:

Be careful to handle P73 Piezo Objective Scanner during installation to avoid damage or scratches and wear of the objective lens.

When connecting the objective lens, the weight of the objective lens shall not exceed the load capacity of P73 Piezo Objective Scanner.



## 5.2 Load

Please refer to the position to mount the load is shown below.




FIG.3 The correct position to mount the load




FIG.4 The error position to mount the load

When connecting the objective lens, it should be noted that the mass of the objective lens should not exceed the load capacity of P73, and the load should not be too long, so as to P73 may be damaged by oscillation.

### 5.3 Operating

Please reconfirm the following information before turning on the power:

- ▶ The operating environment meets the operating environment requirements of P73.
- ▶ Fixed screws must be tightened.

After the above information is confirmed, relevant controller operations can be carried out:

1. Please read the user manual of the controller carefully before operation, and then start the controller.

2. Set the controller's output voltage to zero first.

3. Check no abnormal phenomenon, then input voltage value (via keyboard or analog control) according to specified input voltage range.

4. Operating normally within the rated voltage range of piezoelectric ceramics (0~120V, maximum 150V).

5. After use, please carry out voltage reset operation.

Please take light steps when P73 in operation, do not knock the product, so as not to affect the use of the product or even damage the product.

The resolution of piezo is not limited. It depends on the performance of piezo Controller. In order to achieve better motion precision of P73, it is recommended to use our company's supporting controller. Please refer to the user manual of the controller for the specific operation to ensure correct operation before relevant operation.

#### **Notice:**

- ▶ The driving voltage shall not exceed the voltage range of P73.
- ▶ If any abnormal noise or oscillation occurs during use, turn off the power immediately and check the parameter setting.

## 6. Transportation and inspection

### 6.1 Transportation

This product is packed in cartons. Transportation is carried out under the packaging conditions. This product can be transported by various means of transport under normal circumstances. In the process of transportation, direct rain and snow, corrosive substances, strong collision, extrusion, irregular placement and other improper behaviors should be avoided as far as possible.

### 6.2 Open-Box Inspection

#### **Inspection content:**

- ▶ Before opening the package, please check the outer packing carefully to see if there is any breakage, wetting, dampness, deformation, etc.
- ▶ Please check the completeness of package contents one by one according to the supply contract and packing list.
- ▶ Check whether the surface of the product has obvious damage.
- ▶ Check whether the product identification is clear and complete.
- ▶ Check whether the connector is loose and the connector wire is broken or damaged.

In case of any of the above, please make a detailed record and take a photo of it. Meanwhile, please contact us for processing immediately.

#### **Attention:**

- ▶ Please handle with care when opening the package, so as not to knock against the product and cause permanent damage to it.
- ▶ Please do not use heavy tools or rough way to open.
- ▶ Please do not discard all the packaging materials which are needed for repair and return.



## 7. Maintenance and Treatment

### 7.1 Problem Handling

FAQ are shown in the table below.

Problem description	Possible reason	Solution
No displacement or less displacement	The connection wire is not connected properly or poor contact	Check the connection wire
	Excessive load	Load according to the product' s load capacity
	Sensor zero drift	Check the sensor
Low accuracy	Mountingsurface unevenness	Mount the platform on a flat surface
	Loose connection	Fasten connection
	Wrong connection	Check if the wiring is correct
Vibration or inaccurate positioning at startup	Incorrect input control parameters	Stop immediately and check the parameter Settings
	Resonance occurs	Make drive frequency less than resonance frequency

Table 1 FAQ and solutions

If the user cannot solve the problem by himself in the process of using, please record the problem in detail and contact CoreMorrow, and professional technical personnel will help to solve.

Problems caused by improper operation are not covered by the warranty.

CoreMorrow is not responsible for any problems caused by dismantling products without permission.

## 7.2 Daily maintenance

If the product is not used for a long time, please store it in a dust-free, well-ventilated, clean and non-corrosive indoor environment after packaging.

In the daily maintenance, please do not loosen the bolts on the product structure, so as not to affect the movement accuracy of the product.

### **Daily cleaning:**

Please disconnect the product from the controller before cleaning the surface of the product.

When cleaning, gently wipe the surface of the product with a towel dipped in a small amount of detergent, and then clean it with alcohol. Please do not use ultrasonic cleaner.

When cleaning the surface, try not to pick up the product. If you have to pick up the product, it is better to put the sponge under the product for protection. The product should not be too high from the sponge, in case the product falls off.

## 7.3 Disposal

Waste products should be disposed according to national and local rules and regulations.

In order to fulfill our responsibility as a product manufacturer, we will dispose all old equipments on the market in an environmentally friendly manner. If you have equipment that cannot be disposed, you can ship it to CoreMorrow.

Address: Building I2, No.191 Xuefu Road, Nangang District, Harbin, HLJ, China

Tel: +86-451-86268790



### 8.Customer Service >>

If you have questions about the products you are currently using, please let us know the following information:

- ▷ Product model and relevant number
- ▷ The controller model
- ▷ Software driver version
- ▷ Computer operating system that installs supporting software

### 9.Contact us >>

**CoreMorrow Ltd.**

Tel: +86-451-86268790

Email: [info@coremorrow.com](mailto:info@coremorrow.com)

Website: [www.coremorrow.com](http://www.coremorrow.com)

Address: Building I2, No.191 Xuefu Road, Nangang District, Harbin, HLJ, China

**CoreMorrow Official and CTO WeChat are below:**

