



E63.C1K Series Piezo Controller

User Manual

Version: V1.0



This document describes the following products:

- E63.C1K Open loop USB 1 channel

DECLARATION

Declaration!

This user manual is a integrated user manual of the E63.C1K series piezoelectric controller. Please read this user manual carefully before using this controller. Follow the instructions in the manual during use. If there is any problem, please contact us for technical support. If you do not follow this manual or disassemble and modify the product yourself, the company will not be liable for any consequences arising therefrom.

Please read the following to avoid personal injury and to prevent damage to this product or any other product connected to it. In order to avoid possible hazards, this product can only be used within the specified range.

Notice!

Do not touch any exposed ends of the product and its accessories.

There is high voltage inside. Do not open the case without permission.

Do not connect or disconnect input, output, or sensor cables with power on.

Please keep surface of E63.C1K clean and dry, don't operate in humid or static environment.

After use, output voltage should be cleared to zero before turning off the controller switch, such as switching the servo state to the open-loop state.

Danger!

The piezoelectric power amplifier described in this manual is a high-voltage device capable of outputting high currents, which can cause serious or even fatal damage if not used properly.

It is strongly recommended that you do not touch any parts that connect to the high voltage output.

Special Note: If you connect it with other products in addition to our company, please follow the general accident prevention procedures.

Operating the high-voltage amplification requires training professional operators.

Warning!

If the voltage exceeds the PZT's tolerable range, it will cause permanent damage to the PZT. Before adding voltage to the PZT poles, it must be ensured that the positive and negative poles of the PZT are connected correctly and the operating voltage is within the allowable range of this PZT.

Cautious!

E63.C1K housing should be installed on a horizontal surface in an area with a 3CM air flow area to prevent internal convection in the vertical direction.

Insufficient airflow can cause equipment to overheat or premature instrument damage.

Contents

1. Introduction	2
1.1 Features	2
1.2 Applicaitons	2
2.Driving Principle	2
3.Appearance	3
4.Voltage, Step Time and Load	3
5.Notes and suggestions	4
6.Customer Service	4
7.Contact us	4

1. Introduction


1.1 Features

- ▶ 1 channel small size
- ▶ USB communication control output
- ▶ 5V (USB) power supply
- ▶ Peak current 35mA
- ▶ Ave current 2.5mA
- ▶ Unload bandwidth 1KHz
- ▶ Output short circuit protection

1.2 Applicaitons

- ▶ Driving piezo actuators

2.Driving Principle






3.Appearance



4.Voltage, Step Time and Load



5. Notes and suggestions >>

▶ E63.C1K cannot be used to drive inductive loads. If the inductive loads are driven, the product may be damaged.

6. Customer Service >>

If you have any questions in use, please tell us the following information:

- ▶ Product model and relevant number
- ▶ The controller model
- ▶ Software driver version
- ▶ Supporting computer operating system

7. Contact us >>

Harbin Core Tomorrow Science & Technology Co., Ltd.

Tel: +86-451-86268790

Email: info@coremorrow.com

Website: www.coremorrow.com

Address: Building I2, No.191 Xuefu Road, Nangang District, Harbin, HLJ, China

CoreMorrow Official and CTO WeChat are below:

