

Make Your Motion and Control More Accurate!

# X axis | 400A5 **Amplified Piezo Actuators**

## Characteristics >>

- X Contraction
- Displacement to 410µm
- Fast response
- High resonant frequency
- Various models are available

#### Applications >>

- Probe scanning
- Fiber stretching
- Micro-scanning
- Flow measurement technology Inkjet technology
- Optical mirrors positioning
- Diamond turning
- laser cavity tuning



Harbin Core Tomorrow Science & Technology Co., Ltd.

Tel: +86-451-86268790 Fax: +86-451-86267847

Email: info@coremorrow.com Web: www.coremorrow.com

Headquarters: Building I2, No.191 Xuefu Road, Nangang District, Harbin Shanghai Office: Building 2, No.608 Shengxia Road, Pudong District, Shanghai

Introduction

The amplified piezo actuator is an actuator that amplifies and outputs the displacement generated by low-voltage piezo stacks preloaded by a mechanical amplifying structure.

The amplified structure is an mechanical shell, and its material is generally steel. In addition to providing optimized pre-tightening force for piezo stacks, it also protects piezo stacks from tensile forces that can cause irreversible or even fatal damage to piezo stacks.



Make Your Motion and Control More Accurate!

## Technical Data >>

Туре	400A5	Units
Active axes	Х	
Max/ travel range <sup>[1]</sup>	400	µm±15%
Blocking force	16	Ν
Unloaded resonant frequency	470	Hz±20%
Stiffness	0.04	N/µm±20%
El. capacitance	3.6	μF±20%
Material	Steel	
Operating temperature <sup>[2]</sup>	-20~80	°C
Cable length <sup>[3]</sup>	1.5	m±10mm
Voltage connector <sup>[3]</sup>	Bare wire	

Note: Unless otherwise specified, the above parameters are measured at room temperature about  $25^{\circ}$  C.

[1] Nominal Stroke at  $0\sim150V$ , Max. stroke at  $-20\sim150V$ . Recommended voltage  $0\sim120V$  for long-term and high-reliable operation.

[2] Custom ultralow temperature and ultrahigh vacuum versions are available.[3] Custom cable length and connector is available.

Note: The parameters mentioned above are related to the test environment and test equipment.

# Drawing >>



## Principle >>

Piezo stacks produce deformation and displacement along the main axis, that is, the long axis direction, and the elliptical mechanical structure amplifies and outputs the displacement along the short axis direction.



### Curves >>



Disclaimer: The data here are typical, only for reference. Some variations will occur for different batch.

# Recommended Controllers >>



E01.C1 LCD, membrane button, up to 625mA RS-232/RS-422/USB interface Software secondary development



#### E53.C Small size, 60mA RS-232/RS-422/USB interface Software secondary development



#### Harbin Core Tomorrow Science & Technology Co., Ltd.

Tel: +86-451-86268790 E Fax: +86-451-86267847 V

Email: info@coremorrow.comWeb: www.coremorrow.com

Headquarters: Building I2, No.191 Xuefu Road, Nangang District, Harbin Shanghai Office: Building 2, No.608 Shengxia Road, Pudong District, Shanghai